TECHNICAL MANUAL

ORGANIZATIONAL, DIRECT SUPPORT AND GENERAL SUPPORT MAINTENANCE REPAIR PARTS AND SPECIAL TOOLS LIST (INCLUDING DEPOT MAINTENANCE REPAIR PARTS AND SPECIAL TOOLS)

CHARLES E STUBBS

ILLUSTRATION SUPPLEMENT RAIL, LAUNCHING-HANDLING GUIDED MISSILE, M3A1 1450-00-474-0717

IMPROVED NIKE-HERCULES AIR DEFENSE GUIDED MISSILE SYSTEM

CHARLES E. STUBBS

TM 9-1440-250-24P-6-2

HEADQUARTERS,
DEPARTMENT OF THE ARMY
Washington, D. C., 29 January 1984

THE E STUBBS

Organizational, Direct Support, and General Support Maintenance

Repair Parts and Special Tools List

(Including Depot Maintenance Repair Parts and Special Tools)

ILLUSTRATION SUPPLEMENT

FOR

RAIL, LAUNCHING-HANDLING

GUIDED MISSILE, M3A1

1450-00-474-0717

(IMPROVED NIKE-HERCULES AIR DEFENSE GUIDED MISSILE SYSTEM)

Current as of 2 November 1983

REPORTING OF ERRORS AND RECOMMENDING IMPROVEMENTS

You can help improve this manual. If you find any mistakes or if you know of a way to improve the procedures, please let us know. Mail your letter, DA Form 2028 (Recommended Changes to Publications and Blank Forms), or DA Form 2028-2 located in back of this manual direct to: Commander, U. S. Army Missile Command, ATTN: DRSMI-SNPS, Redstone Arsenal, AL 35898. A reply will be furnished to you.

Table of Contents

			Page
Section	I.	Introduction	1-1
		Illustrations, Assembly Parts Breakdown	
	III.	Illustrations	
	IV.		3-1
	110	Numerical Index	4-1

^{*}This manual supersedes TM 9-1440-250-24P-6-2, dated 4 August 1980.

Section I. INTRODUCTION

1. Scope.

This manual depicts illustrations that will aid in the identification of authorized spares and repair parts; special tools, special test, measurement and diagnostic equipment (TMDE), and other support equipment, required for performance of organizational, direct support and general support maintenance of the Rail, M3Al.

2. General.

This Repair Parts and Special Tools List Illustration Supplement is divided into the following sections:

- a. Section II. Illustrations, Assembly Parts Breakdown. This section is divided as follows:
- (1) Assembly Parts Breakdown List. This list is furnished to aid in locating components, assemblies, and subassemblies and indicates by indenture the generation breakdown level of the item.
- (2) Cross-Reference Numercial List. This list is furnished as an aid in locating items by part number that appear on the assembly parts breakdown list.
- b. Section III. Illustrations. A series of exploded views of assemblies and subassemblies arranged in figure number sequence. All exploded parts are identified with callout numbers placed in clockwise sequence. The first illustration will depict the end item followed by an exploded view illustration or series of illustrations of the major assembly prior to the breakdown of its subassemblies. The subassemblies are then illustrated in the order that they appeared and were indexed on the major assembly.
- c. Section IV. Numerical Index. A list, in alphanumeric sequence, of all part numbers appearing in the illustration legends. Part numbers are cross-referenced to each illustration figure and item number appearance. This index is furnished as an aid in locating items in this supplement, and authorized items in the Repair Parts and Special Tools List.

3. Special Information.

- a. Repair Parts and Special Tools List. The listing of authorized repair parts for the equipment contained in this illustration supplement are located in TM 9-1440-250-24P-6-1, Repair Parts and Special Tools List. Items that appear on the illustrations, but which are not listed in the Repair Parts and Special Tools List, are not authorized repair parts. In such cases, or where differences exist between information found in this Supplement and the Repair Parts and Special Tools List, the information found in the Repair Parts and Special Tools List manual will prevail for requisitioning purposes.
- b. Quantity Per Illustrated Application. The quantity per illustrated application will be shown in the legend to the right of the referenced number. The asterisk (*) shown on the illustration legend denotes "as required."

c. Wiring Harnesses. Wiring harnesses that require a separate illustration(s) for component identification, or cable asemblies and test leads composed of common type components, have been assigned a control number and the component parts are identified at the end of Section III. The assembled items are identified at their first appearance and refer to an illustration for details. The referenced illustration depicts all components of the wiring harnesses, cable assemblies, or test leads. Following the referenced illustration is an application page(s) listing the components and quantities per each wiring harness, cable assembly, or test lead.

4. How to Locate Repair Parts.

- a. When National stock number or part number is unknown:
- (1) First. Using the table of contents, find the Illustrations, Assembly Parts Breakdown.
- (2) <u>Second</u>. Using the Illustrations, Assembly Parts Breakdown, determine the assembly within which the repair part belongs.
- (3) Third. Find the illustration covering the assembly to which the repair part belongs.
- (4) Fourth. Identify the repair part on the illustration and note the part number of the repair part.
- (5) Fifth. Refer to paragraph 3.a. above to determine the applicable TM where authorized repair parts are depicted. This is necessary since compatible repair parts and special tools for this supplement are shown in a separate Repair Parts and Special Tools List manual.
- (6) Sixth. Using the Index of National Stock Numbers and Part Numbers of the Repair Parts and Special Tools List, find the pertinent part number of item noted on the illustration. This index is in National item identification number (NIIN) sequence followed by a list of part numbers in alphanumeric sequence, cross-referenced to the index numbers shown in the illustration figure and item number column.
- (7) Seventh. After finding the index number in the figure and item number column of the Repair Parts and Special Tools List, locate the index number in the repair parts list.
 - b. When National stock number or part number is known:
- (1) First. Refer to paragraph 3.a. above to determine the applicable TM where authorized repair parts are depicted. This is necessary since compatible repair parts and special tools for this supplement are shown in a separate Repair Parts and Special Tools List manual.

- (2) Second. Using the Index of National Stock Numbers and Part Numbers of the Repair Parts and Special Tools List, find the pertinent National Stock Number or part number. This index is in NIIN sequence followed by a list of part numbers in alphameric sequence, cross-referenced to the index numbers shown in the illustration figure and item number column.
- (3) Third. After finding the index number in the figure and item number column of the NSN or Part Number Index of the Repair Parts & Special Tools List, locate the index number in the repair parts list.

SECTION II.

ILLUSTRATIONS, ASSEMBLY PARTS BREAKDOWN

 Assembly Parts Breakdown List Note: The use of dots indicates g 		-WHEEL ASS	Instration Title	Figure No.
breakdown.	generation		/	20
likestration Title	200	-WHEEL ASS		28
	Pigure No.		/	20
RAIL, LAUNCHING-	•	-CYL INDER		29
HANDLING. GUIDED			G. LINEAR	
MISSILE + M3A1 /9027441/	1		AND 8521453/-	20
RELEASE ASSEMBLY,		- PRAKE- IA	UNCHING RAIL	30
LAUNCHING RAIL		/8525285	/	22
/9032212/	10	. 0723203		32
BREAKAWAY ASSEMBLY,				
LAUNCHING RAIL				
/8525300/	11	2. Cross-R	eference Numerical Li	-
ELECTRICAL		Reference No.	Assembly	
INSTALLATION,			•	Pigure No
LAUNCHING RAIL		11067500	CABLE	
/8167172/	12		ASSEMBLY,	
.CABLE ASSEMBLY SWITCH			POWER,	
/8167414/	16		ELECTRICAL	23
-CABLE ASSEMBLY SWITCH		11067515	CONNECTOR.	
/8167414/	17		PLUG,	
CABLE ASSEMBLY			ELECTRICAL	
/13060170/	18		ASSEMBLY	25
CABLE ASSEMBLY		11067544	CABLE	
/8167527/	19		ASSEMBLY,	
SHITCH SUBASSEMBLY			POWER,	
/8527134/	20		ELECTRICAL	23
HOUSING, SENSITIVE		13060170	CABLE	
SWITCH /15605-49-			ASSEMBLY	18
3161/	21	49-3161	HOUS ING.	
.BELL ASSEMBLY,			SENSITIVE	
ELECTRICAL			SWITCH	21
INSTALLATION /8527036		8167172	ELECTRICAL	
AND 8527037/	22		INSTALL A-	
.CABLE ASSEMBLY. POWER.			TION,	
ELECTRICAL /11067500			LAUNCHING	
AND 11067544/	23		RAIL	12
CONNECTOR, PLUG.		8167414	CABLE	46.46
ELECTRICAL /8526871/	24		ASS EMBLY	
CONNECTOR, PLUG,			SWITCH	16
ELECTRICAL ASSEMBLY		8167416	WHEEL	
/11067515	25		ASSEMBLY	28
RELAY ASSEMBLY,		8167435	WHEEL	
BLOWER /8521464/	26	24000	ASSEMBLY	29
TERMINAL BOARD		8167527	CABLE	-
/8525120 AND 8525121/	27		ASSEMBLY	19

Reference No.	Assembly	Pigure No.	Reference No.	Assemblu	
8521441	CYL INDER				Figure No.
	ASSEMBLY,		8527036	BELL	
	ACTUATING.			ASSEMBLY,	
	•			ELECTRICAL	
8521453	LINEAR	30	2000	INSTALLATION	22
0321433	CYLINDER		8527037	BELL	
	ASSEMBLY,			ASSEMBLY,	
	ACTUATING,			ELECTRICAL	
0800444	LINEAR	30		INSTALLATION	22
8521464	RELAY		8527134	SWITCH	26
	ASS EMBLY,			SUBASSEMBLY	20
	BLOWER	26	9027441	RAIL.	20
8525120	TERMINAL			L AUNCHING-	
	BOARD	27		HANDLING,	
8525121	TERM INAL		4	GUIDED	
	BOARD	27	*	MISSILE.	
8525285	BR AK E.			M3A1	
	LAUNCHING		9032212		1
	RAIL	32	JOSEFIE	RELEASE	
8525300	BREAKAHAY	34		ASSEMBLY,	
	ASSEMBLY,			LAUNCHING	
	LAUNCHING			RAIL	10
	RAIL	11			
8526871	CONNECTOR,	**			
	PLUG,				
	ELECTRICAL				
	CCCCIKICAL	24			

SECTION III.




FIGURE 1. RAIL. LAUNCHING-HANDLING. GUIDED MISSILE. M341 /9027441/




FIGURE 2. RAIL, LAUNCHING-HANDLING, GUIDED MISSILE, MBA1 /9027441/




FIGURE 3. RAIL, LAUNCHING-HANDLING, GUIDED MISSILE, MIAI /9027441/




FIGURE 4. RAIL, LAUNCHING-HANDLING, GUIDED MISSILE, MIAL /9027441/





FIGURE 5. RAIL, LAUNCHING-HANDLING, GUIDED MISSILE, MBAL /9027441/



1	BREAKAWAY ASSEMBLY
	85253001
	SEE FIGURE 11 FOR DETAILS
2	SPRING 8525274
3	GUARD 85252882

5	SCRE N MS35206-26040 MASHER MS35333-3928
6	ELECTRICAL INSTALLATION
	8167172
	SEE FIGURE 12 FOR DETAILS

FIGURE 6. RAIL, LAUNCHING-HANDLING, GUIDED MISSILE, MAI /9027441/




FIGURE 7. RAIL. LAUNCHING-HANDLING. GULDED MISSILE, MIAL /9027441/




FIGURE 8. RAIL. LAUNCHING-HANDLING. GUIDED MISSILE, M3A2 /9027441/






FIGURE 9. RAIL, LAUNCHING-HANDLING, GUIDED MISSILE MIAI /9027441/



1	HULDER 9020383	10	BOLT 85218821	19	#IRE QQ#390CONDITIONA
- 2	CUUPLING 9020401	- 11	BRACKET ASSEMBLY 9032134	20	PIN 84282692
3	#45 rtcR MS 27163-231	12	MASHER MS35338-44		SETSCREW MS51963-68
4	NUT 9020398 2	1.3	SCREW MS90725-32	22	PIN 90203812
	PIN M524005-155*********************************	14	PIN 85243771		FITTING 90188402
i i	Y DKE ASSEMBLY 4032143	15	HUUSING 8524384		THUMBS CREW 9151815
	7 BUSHING 8524385	16	SPR ING 8165440		MASHER MS35338-1411
	8 BUSHiNG 91516432	1.7	MASHER MS20002-85		NUT M535691-23
9	PIN 90203971		PIN MS16562-365		

FIGURE 10. RELEASE ASSEMBLY, LAUNCHING RALL /9032212/ /SEE FIGURE 2 FOR NEXT HIGHER ASSEMBLY/



3 4 5 6	PIH ASSEMBLY 9019300	10	STOP BRACKET ASSEMBLY 8525318	21 22 23 24	HOLDER 11067518
---------	----------------------	----	-------------------------------	----------------------	-----------------

FIGURE 11. BREAKAWAY ASSEMBLY, LAUNCHING RAIL /8525300/ /SEE FIGURE 6 FOR NEXT HIGHER ASSEMBLY/




FIGURE 12. ELECTRICAL INSTALLATION, LAUNCHING RAIL /8167172/ /SEE FIGURE 6 FOR NEXT HIGHER ASSEMBLY/




FIGURE 13. ELECTRICAL INSTALLATION, LAUNCHING RAIL /0167172/




FIGURE 14. ELECTRICAL INSTALLATION, LAUNCHING RAIL /B167172/






FIGURE 15. ELECTRICAL INSTALLATION, LAUNCHING RAIL /8167172/




3 6 5 6	OKALKET 1104 1672	8 9 10	MUT #535650-3022	13 14 15	MOUNTING PLATE 81674131 PLATE 81674941 MASHER MS27183-82 BOLT AN3C14A2 WASHER MS27183-142
---------	-------------------	--------------	------------------	----------------	---



MS009949


FIGURE 17. CABLE ASSEMBLY SMITCH /8167414/ /SEE FIGURE 12 FOR NEXT MIGHER ASSEMBLY/




AS010150

1 2	BUX CONNECTOR 91117451 SWITCH/ HRACKET ASSEMBLY 13060166	6 BRACKET 13060167	11 12 13	10 RECEPTACLE ES TERMINAL NS 25036-103. TERMINAL B526780 CABLE 070618
-----	--	--------------------	----------------	--

FIGURE 18. CABLE ASSEMBLY /13040170/ /SEE FIGURE 17 FOR NEXT HIGHER ASSEMBLY/






RETAINER 15605-55-534.....2 TERMINAL BOARD 15605-17-

CONTACT 15605-21-308-3----2
GLIP 15605-69-919------1
PLATE 15605-56-1225------1

* COMPONENT OF SWITCH SJBASSEMBLY 8527134


FIGURE 20. SHITCH SUBASSEMBLY /4527134/ /SEE FIGURE 19 FOR NEXT MIGHER ASSEMBLY/



HOUSING 15605-49-1819------1 SPRING 8527169-------1 MASHER 15605-16-909------1

7 WASHER 15605-916-4842......4 8 SCREW 15605-911-5002.....4

FIGURE 21. HOUSING, SENSITIVE SMITCH /15605-69-3161/ /SEE FIGURE 19 FOR NEXT HIGHER ASSEMBLY/



DRD G297306

3	5505	6	BOUT	84282921 84282901 W MS35207-2604	**	FOR FOR	BELL BELL	ASSEMBLY 8527036 ASSEMBLY 8527037
---	------	---	------	--	----	------------	--------------	--------------------------------------

FIGURE 22. BELL ASSEMBLY, ELECTRICAL INSTALLATION /8527036 AND 8527037/ /SEE FIGURE 12 FOR NEXT HIGHER ASSEMBLY/





FIGURE 23. CABLE ASSEMBLY, PUMER, ELECTRICAL /11067500 AND 11067544/ /SEE FIGURES 12 AND 15 FOR MEXT HIGHER ASSEMBLY/



> FIGURE 24. CONNECTOR. PLUE, ELECTRICAL /8526871/ /SEE FIGURE 23 FOR NEXT HIGHER ASSEMBLY/






FIGURE 25. CONNECTOR. PLUG. ELECTRICAL ASSEMBLY /11067515 /SEE FIGURE 23 FOR NEXT HIGHER ASSEMBLY/




4	NUT MS 21083NO6	8	SCREW MS51957-28
---	-----------------	---	------------------

FIGURE 26. RELAY ASSEMBLY. BLONER /8921464/ /SEE FIGURE 15 FOK NEXT HIGHER ASSEMBLY/



NUT MS21083N00	7 MASHER T1002				
4 BASE T1006-21	10 BRACKET T10051	**			
5 BOARD T1006-11	11 SCREW MS51957-3210 12 WASHER MS27183-510				
6 CLIP \$10032	IZ MRAMER MAETIOS-Jonoscovo-e-17				

^{*} COMPONENT OF TERMINAL BOARD B525120 AND 8525121 ** FOR TERMINAL BOARD 8525120 ** FOR TERMINAL BOARD 8525121



I RING MS16625-1315------2 SLEE VE 11067563.....1 BEARING 8528201.....2

FIGURE 28. WHEEL ASSEMBLY /8167416/ /SEE FAGURE B FOR NEXT HIGHER ASSEMBLY/




FIGURE 29. WHEEL ASSEMBLY /8167435/ /SEE FIGURE 8 FOR NEXT HIGHER ASSEMBLY/

BEARING 8528201.....2 SPACER 8167420.....1 GEAR 8167434.....1

7 WHEEL 8167436......4




FIGURE 30. CYLINDER ASSEMBLY, ACTUATING, LINEAR /8521441 AND 8521453/ /SEE FIGURE 9 FOR NEXT HIGHER ASSEMBLY/




FIGURE 31. CYLINDER ASSEMBLY, ACTUATING, LINEAR /8521441 AND 8521453/




FIGURE 32. BRAKE, LAUNCHING RAIL /8525285/ /SEE FIGURE 9 FOR NEXT HIGHER ASSEMBLY/

SECTION IV. NUMERICAL INDEX

REFERENCE NUMBER	40 F1		REFERENCE Number	FIG	1150	PESCOPA		
AN115409	,	13 21		ND.	NO.	REFERENCE NUMBER	FIG. NO.	4 100
4N115411		41	MILT6845 1-4X-	035				Nn.
AN3-3A	1	3 20		7	12	M520068-122	8	16
	1	1 17		7		MS20074-10-23	2	
AN3-7A	1	2 18	MS1 6555-60			MS20392-5C31	•	7
AN3C14A			M\$16562-3		5		4 5	5
	1	. 73		32		MS20392-7095	,	19
AN4-11A			MS16562-33	11	21		11	7
AN415-1-2	1;	23	MS16562-34	11		M250819-4	7	11
- Tribanda	4 5		MS16562-36	**	3	MEAAA	7	24
4N520-0-2				10	18	M527819-4J	7	3
_	3	9	M\$16562-49	32	15	MS21044NO8	7	19
Ah6-11	4	9	MS16562-50	9	11		14	1
AN6230-7	30			32	6	MS21044N3	12	17
AN814-2		8	M21 6565-65	4	2		15	3
AMB14 4 4	30	1	MS16562-8		٤	MS21044N4	12	20
AN816-4-4C	7	7		32	7	MS21083N06	-	6.0
AN818-4	7	10	H\$16624-1087	5	4		26 27	4
•	7	23	MS16625-1315	28	1	MS21063N3	13	
A NO 18-4C	7	2	Man.	29	1	MS21104C10		ø
	7	18	MS16626-1059		24	MS21105-18	15	25
AN824-4C	7	13	MS16626-1068		12		13	9
AN633-C4	7	5	MS16626-1137	-		MS21919WH16	13	30
AN924-4J	-	3		28 29	5	M\$21920-26R		-
AN960-10	7	6	MS16627-1093	***	_	MS2439404	3	13
	12	16	MS16632-1037	31	13		30	23
AN960-1216L	8	11		23	4	MS24395J4	7	21
AN960-416	Ľ2		MS16998~Z9	22	1	M\$24400D4	30	
4N960C1616L		21	MS16998-55	30	-	MS24629-20	-	52
	8	19	MS1 6998-59		20		2	4 30
1N960C616L	11	24	MS17821-1-9	31	3	M\$24665-155		_
50071	18	0		14	10	MS24665-302	10	5
50RA			MS17821-2-2	14	11		11	4
50SA	18	10	M518154-60	P		MS24668-11	8	3
	18	8	MS20002-8		15	MS25036-103	18	
ILC13777-2-090675	15	10		10	17		19	11 24
			MS20067-118	5	13	MS 25043-320	26	3
						······································	13	18

FIG. NO.

TTEM ND₄

REFERENCE NUMBER

REFERENCE NUMBER	FIG NO.		KCHERENCE	
	7-20	₩ŋ.	NUMBER	FIG. ITEM
8530889	32	2 10	9032143	
8530890	32	2 16		10 6
8530897	32	19	9032212	2 11
B530898	32		9032471	5 14
8530904	32		9032472	4 15
9003262	13	25	9032475	4 16
9017736	14	8	9034320	z ₁
9017737	2		911-4367	19 23
9018424	19	17	911-500Z	Z1 g
9018668-I	15	12	9111745	12 1
9018849		11		18 Î 19 Î
	5	10	9112718	15 13
	a 10	33 23	9151244	
9019000	9	4	010100	32 15
9019275	11	2	9151329	8 13
9019300	11	1	9151469	8 34
9020154	16	2	9151643	10 g
9020381	17	2	9151815	10 24
9020383	10	22	9152160	14 7
	10	1	9153488	2 12
9020397	10	9	916-4842	21 7
9020398	10	4	94	12 4
9020401	10	2	9977969	19 4
9022333	12	15	9977153	12 19
9025043	3	17	9977163	8 4
9025044	3	12	9977164	12 22
9025991	30	5		12 24
9025992	30	6	9977579	3 22
9026936-1	15	9	9977596	3 26
9029768		10	9977597	3 25
9029795		11	9977598	3 23
9029931	_		9977602	3 29
9029934		16	9978397	3 5
9030169		17	9978398	3 7
9031249		.8	9978399	3 4
		6	9978400	
9031260	9 1		9978401	-
9031263	32 1		9979094	_
9031878	32 13	3		3 1
9032134	3 14			
- V26634	10 11			



REFERENCE NUMBER	FIG.	ITEM NO.	REFERENCE Number	FIG.	ITEM NG.	REFERENCE NUMBER	FIG.	ITE
8530889	32	10	9032143	10			140.0	NP.
8530890	32	16	9032212		6			
8530897	32	19	9032471	2	11			
8530898	32	11	9032472	5	14			
8530904	32	9	9032475	4	15			
9003262	13	25	9034320	4	16			
9017736	16	8	911-436Z	2	1			
9017737	2	17	911-500Z	19	23			
9018424	19	12	9111745	21	8			
9018658-1	15	11	********	12 18	1			
9018849	4	10	9112718	19	1			
	5 8	7 33	9151244	15	13			
5.61.04.00	10	23	******	9 32	15 2			
9019000	9	4	9151329	8	13			
9019275	11	2	9151469		34			
9019300	11	1	9151643	10	8			
9020154	16 17	2	9151615	10	24			
9020381	10	22	9152160	14	7			
9020383	10	1	9153488	2	12			
9020397	10	9	916-4842	21	7			
9020398	10	4	94	12	4			
9020401	10	2		19	4			
9022333	12	15	9977969	12	19			
9025043	3	17	9977153	8	4			
9025044	3	12	9977163	12	22			
9025991	30	5	99771 <i>6</i> 4 9977579	12	24			
9025992	30	6		3	22			
9026936-1	15		9977596	3	26			
9029768	8	9	9977597	3	25			
9029795	3	10	9977598	3	23			
9029931	7	11	9977602	3	29			
9029934		16	9978397	3	5			
9030169	7	17	9978398	3	7			
9031249	32	10	9978399	3	4			
	32	18	9978400	3	8			
9031260	9	10	9978401	3	2			
0.031242	32	17	9979094	3	1			
9031263	32	13						
9031878	3	14						
903 21 34	10	11						



								LII U
REFERENCE Number	FIG.	ITEM NO.	REFERENCE NUMBER	FIG.	ITEM	. DELEMENTE	FIG.	î TEN
T1004	27	9	16-223		40.5	NUMBER	NO.	Nn.
T1005	27			19	20	8022006	15	22
T1006-1	27		16-42	19	52	8031053	13	10
T1006-2	27	4	16-929	51	3	8031098	12	27
0.5	12	3	17-1774-2	20	2	8034459	31	
	19	3	17-1775-2	19	16	8034483	31	8
070618	18 19	13	20-722	21	6	816-401	19	19
10015592-050	30	26	21-308-3	20	4	8165440	10	21
10596841-1	30	3	21-507-2	19	15	8167019		16
	30	11 21	21-507-3	19	14	8167026	8	27
11-419	19	13	2610655	23	14	8167037	8	26
11-624	19	6	27-294	19	11	0167121	4	3
11067500	19	17	30-489	19	9	8167172	31	10
	12	29	43164	12	2		6	.6
11067504	11	25	60-1010	19	2	8167388	13	23
11067508	23	15	49-1819	21	1	6167393	13	12
11067511	25	6	49-2785	19	10	8167412	16 17	4
11067512	25	9	49-2785-2	19	7	8167413	16	5
11067515	23	9	49-3161	19	19		17	12 11
11067517	2	19	51-858	21	5	8167414	12	5
11067518	11	18	5183444	24	2	8167416	8	1
11067528	13	2	5183447	25	2	8167417	28	5
11067544	15	19	51 834 48	12	11	8167418	8	20
11067546	8	32	•	12	9	8167420	28	6
11067553	9	13	540631	24	7	******	29	5
	32	23	540683	25	7	8167422	6	8
11067554	9	17	55-534	20	1	8167434	29	6
11067555	32	1	5578538	12	10	8167435	8	6
11067556	32	12	56-1225	20	6	8167436	29	7
11067561	32	20	586088	30	7	8167445	8	23
11067563	13	9	589919	31	15	8167452	8	5
£007703	28 29	3		29	8	8167465	32	14
11067572	16	5	5952134	30	9	8167494	16	13
11067574	25	8	69-919	20	5	014-4	17	12
12-198	19		69-920	20	3	8167495	6	9
13060166	18	8	7632546	24	4	8167497	5	6
13060167	19 17	5	7632547	24	3	8167501	4	11
	18	6	7632548	24	1	8167506	2	3
13060168	18	2	7632550	24	5	8167527	16	6
13060170	17	6				8167585	12	12
16-1710	21	4	8020622	23	10	8167617	2	28
			8022002	15	23	8167618	2	5

By Order of the Secretary of the Army:

JOHN A. WICKHAM, JR. General, United States Army Chief of Staff

Official:

ROBERT M. JOYCE
Major General, United States Army
The Adjutant General

Distribution:

To be distributed in accordance with DA Form 12-32, Section II, Organizational Maintenance requirements for NIKE-HERCULES Missile System.

		$\hat{}$
		^

		7.3